Coast Guard, DHS § 168.50

§ 168.10 Responsibilities.

- (a) The tanker owner or operator shall:
- (1) select escort vessels that can meet the performance requirements of this part; and
- (2) inform the tanker master of the performance capabilities of the selected escort vessels. This information must be provided to the master before beginning the escort transit.
- (b) The tanker master shall operate the tanker within the performance capabilities of the escort vessels, taking into account speed, sea and weather conditions, navigational considerations, and other factors that may change or arise during the escort transit.
- (c) In an emergency, the tanker master may deviate from the requirements of this part to the extent necessary to avoid endangering persons, property, or the environment, but shall immediately report the deviation to the cognizant Coast Guard Captain of the Port (COTP).

§ 168.20 Applicable vessels.

The requirements of this part apply to laden, single hull tankers of 5,000 gross tons or more.

§168.30 Applicable cargoes.

The requirements of this part apply to any petroleum oil listed in 46 CFR Table 30.25–1 as a pollution category I cargo.

§ 168.40 Applicable waters and number of escort vessels.

The requirements of this part apply to the following waters:

(a) Prince William Sound: Each tanker to which this part applies must be escorted by at least two escort vessels in those navigable waters of the United States within Prince William Sound, Alaska, and the adjoining tributaries, bays, harbors, and ports, including the navigable waters of the United States within a line drawn from Cape Hinchinbrook Light, to Seal Rocks Light, to a point on Montague Island at 60°14.6′ North, 146°59′ West, and the waters of Montague Strait east of a line between Cape Puget and Cape Cleare.

(b) Puget Sound and certain associated waters: Each tanker to which this part applies must be escorted by at least two escort vessels in those navigable waters of the United States and Washington State east of a line connecting New Dungeness Light with Discovery Island Light and all points in the Puget Sound area north and south of these lights. This area includes all the navigable waters of the United States within Haro Strait, Rosario Strait, the Strait of Georgia, Puget Sound, and Hood Canal, as well as those portions of the Strait of Juan de Fuca east of the New Dungeness-Discovery Island line.

§ 168.50 Performance and operational requirements.

- (a) Except as provided in paragraph (c) of §168.10, at all times during the escort transit each tanker to which this part applies:
- (1) Must be accompanied by escort vessels that meet the performance requirements of paragraph (b) of this section (but not less than the number of escorts required by §168.40).
- (2) Must have the escort vessels positioned relative to the tanker such that timely response to a propulsion or steering failure can be effected.
- (3) Must not exceed a speed beyond which the escort vessels can reasonably be expected to safely bring the tanker under control within the navigational limits of the waterway, taking into consideration ambient sea and weather conditions, surrounding vessel traffic, hazards, and other factors that may reduce the available sea room.
- (b) The escort vessels, acting singly or jointly in any combination as needed, and considering their applied force vectors on the tanker's hull, must be capable of—
- (1) Towing the tanker at 4 knots in calm conditions, and holding it in steady position against a 45-knot headwind;
 - (2) [Reserved]
- (3) Holding the tanker on a steady course against a 35-degree locked rudder at a speed of 6 knots; and
- (4) Turning the tanker 90 degrees, assuming a free-swinging rudder and a speed of 6 knots, within the same distance (advance and transfer) that it

§ 168.60

could turn itself with a hard-over rudder.

[CGD 91-202, 59 FR 42968, Aug. 19, 1994, as amended at 70 FR 55730, Sept. 23, 2005]

§ 168.60 Pre-escort conference.

- (a) Before commencing an escort transit, the tanker master shall confer, by radio or in person, with the tanker pilot and the masters of the escort vessels regarding the escort operation.
- (b) The purpose of the pre-escort conference is for all parties to plan and discuss particulars of the escort transit.
- (c) At a minimum, the following topics must be addressed during the preescort conference:
- (1) The destination, route, planned speed, other vessel traffic, anticipated weather, tide, and sea conditions, and other navigational considerations;
- (2) The type and operational status of communication, towing, steering, and propulsion equipment on the tanker and escort vessels;
- (3) The relative positioning and reaction time for the escort vessels to move into assist positions, including, if appropriate, pre-tethering the escort vessels at crucial points along the route;
- (4) The preparations required on the tanker and escort vessels, and the methods employed in making an emergency towline connection, including stationing of deck crews, preparation of messenger lines, bridles, and other towing gear, and energizing appropriate deck equipment;
- (5) The manner in which an emergency towline connection would be made (which escort vessel will respond, how messengers and towlines will be passed, etc.):
- (6) Other relevant information provided by the tanker master, pilot or escort vessel masters.

PART 169—SHIP REPORTING SYSTEMS

Subpart A—General

Sec.

169.1 What is the purpose of this part? 169.5 How are terms used in this part de-

fined? 169.10 What geographic coordinates are used? 169.15 Incorporation by reference: Where can I get a copy of the publications mentioned in this part?

Subpart B—Establishment of Two Mandatory Ship Reporting Systems for the Protection of Northern Right Whales

- 169.100 What mandatory ship reporting systems are established by this subpart?
- 169.102 Who is the shore-based authority?
- 169.105 Where is the northeastern reporting system located?
- 169.110 When is the northeastern reporting system in effect?
- 169.115 Where is the southeastern reporting system located?
- 169.120 When is the southeastern reporting system in effect?
- 169.125 What classes of ships are required to make reports?
- 169.130 When are ships required to make reports?
- 169.135 How must the reports be made?
- 169.140 What information must be included in the report?

Subpart C—Transmission of Long Range Identification and Tracking Information

- 169.200 What is the purpose of this subpart? 169.205 What types of ships are required to transmit LRIT information (position reports)?
- 169.210 Where during its international voyage must a ship transmit position reports?
- 169.215 How must a ship transmit position reports?
- 169.220 When must a ship be fitted with LRIT equipment?
- 169.225 Which Application Service Providers may a ship use?
- 169.230 How often must a ship transmit position reports?
- 169.235 What exemptions are there from reporting?
- 169.240 When may LRIT equipment be switched off?
- 169.245 What must a ship master do if LRIT equipment is switched off or fails to operate?

AUTHORITY: 33 U.S.C. 1230(d), 1231; 46 U.S.C. 70115, Department of Homeland Security Delegation No. 0170.1.

SOURCE: USCG-1999-5525, 64 FR 29234, June 1, 1999, unless otherwise noted.

Subpart A—General

§ 169.1 What is the purpose of this part?

This subpart prescribes the requirements for mandatory ship reporting systems. Ship reporting systems are